


Setup Instructions

WARNING:

OPEN SUKKAH IN WIDE AREAS ONLY.

BEFORE ATTEMPTING TO CLOSE, READ THE CLOSING INSTRUCTIONS, ALSO PERMANENTLY SEWN ONTO THE SUKKAH.



Picture A




Picture B

1. Remove the elastic band and toss the Sukkah up and away from you.
(see pictures A & B)

*GRAY RODS go
INSIDE the Sukkah*

*BLACK RODS go
OUTSIDE the Sukkah*




Picture C

2. Stand Sukkah up straight (See picture C).
3. First insert the Gray rods into the tabs at the top inside of the Sukkah. Next insert the upper and lower black rods into the tabs on the outside side and back of Sukkah. (See picture C).
4. Use the buckle straps on the back to attach the Sukkah to a stable object. (For Kosher guidelines, see the inside back wall of the Sukkah.)

For more information:

Visit us at **popupsukkah.com**

or call us at **(888) POP-UP44**



Picture D




Picture E

5. Lay the bamboo support sticks on top of the inside side rods and secure the ends of the sticks inside the elastic band rings hanging from the top of the side walls (see picture D).

6. Lay the Schach mat on top of the bamboo support sticks but underneath the "X" fabric in a roll, and unroll (see picture E).

Picture F


When placed on grass, the Sukkah can be secured to the ground at the front and back with the tent pegs provided (see picture F).



Attach to a stable object like a street sign or a car using both buckle straps.

Additional instructions for the large Sukkah

Insert the long rubber tipped gray rods vertically into the pockets located in the middle of the inside side walls at the top and the bottom (see picture G).




Picture G

For more information:
 Visit us at **popupsukkah.com**
 or call us at **(888) POP-UP44**


Closing Instructions

BEFORE ATTEMPTING TO CLOSE,
READ INSTRUCTION SHEET, ALSO PERMANENTLY SEWN TO SUKKAH.


- 1) Tip the Sukkah on its side and stand facing its base, with the door open and to the right (see picture A).





- 2) Stand so that the tips of your feet are on the bottom rim. With your palms facing up, and your hands about 2 feet apart, grasp both rims at the top (see picture A).



- 3) With both rims grasped firmly, push your right hand down and inward towards your left foot. Then fold the Sukkah over by pulling your left hand over towards your right foot (see picture B). The Sukkah should now be flat on the ground (see picture C).




- 4) With the Sukkah on the ground in front of you, place both feet on the base and kneel as illustrated. With both hands, grasp the 2 rims firmly (see picture D).



- 5) Twist the upper part of the Sukkah by pulling your right hand towards your left shoulder. Now complete the twist by pushing your left hand around towards your right hip (see picture E).

- 6) The Sukkah should now look like 2 flattened disks (see picture F). Fold the top half down onto the bottom half and flatten (see picture G).

Turn the Sukkah on its edge and slide the elastic band around it (see picture H). Slide the folded Sukkah back into the bag.



For more information:
Visit us at popupsukkah.com
or call us at (888) POP-UP44